Nikon D1 Custom Settings Highlights by Rob Galbraith

print out, trim and attach to inside of LCD screen cover

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400

D1 Custom Settings Highlights
Image status in single-frame shooting mode
1-0 Disabled; 1-1 Capture-Preview; 1-2 Record-and-Review
Autofocus activation
4-0 Shutter release activates AF; 4-1 AF activ. by AF-ON button only
Anti-vibration mode
5-0 disabled; 5-1 Enabled
Mirror up for CCD cleaning
8-0 Mirror down; 8-1 Mirror up
Self-timer duration
16-x (duration in seconds)
Sharpening (JPEGs and TIFFs only)
23-0 Normal; 23-1 Low; 23-2 High; 23-3 None
Tone compensation
24-0 Auto; 24-1 Normal; 24-2 Low; 24-3 High; 24-4 Custom
LCD monitor display mode
27-0 Image; 27-1 Image/Histogram; 27-2 Image/Highlights; 27-3 All
Shooting mode when camera set to PC (FireWire)
30-S Single frame shooting; 30-C Continuous shooting
ISO 3200 and 6400
31-0 Disabled (ISO 1600 max); 31-1 ISO 3200; 31-2 ISO 6400